



# Lo Torque Hole Opener

Metric sizes



## LT hole opener specifications

Body				Cutters			
Body	Min pilot hole	Connections	No of cutters	Opening range			
LT2	6.4	2" IF P x B	3	15.2			
LT4	11.4	2 7/8" IF P x B	3	20.3	25.4		30.5
LT6	16.5	3 1/2" IF P x B	3	30.5	35.6		40.6
				A	B	C	D
LT8	21.6	4 1/2" IF P x B	3	40.6	45.7	50.8	55.9
LT16	40.6	7 5/8" Reg. P x B	3	61.0	66.0	71.1	76.2
LT24	61.0	7 5/8" Reg. P x B	4	81.3	86.4	91.4	96.5
LT32	81.3	7 5/8" Reg. P x B	4	106.7	111.8	116.8	121.9
LT40	101.6	7 5/8" Reg. P x B	4	121.9	127.0	132.1	137.2
LT48	121.9	7 5/8" Reg. P x B	5	137.2	142.2	147.3	152.4

\* Thread connections mentioned are in standard sizes. Other connections are available upon request.

## Cutter specifications

### Milled Tooth

Alluvial formations, clays, soft rock.  
3–21 Mpa (500–3,000 PSI) compressive strength formations.

**Formation types:** Sandstone, shale, mudstone, clays, gravels and conglomerate.

Teeth are milled directly from the hard cone steel and tungsten hardfacing applied on the trailing edge to maintain sharpness of the blade. TCI gage row MT cutters available on special order.

### TYPE 7 (IADC)

Medium – hard rock  
83–172 Mpa (12,000 - 25,000 PSI) compressive strength rock

**Formation Types:** Granite, marble, and dolomite.  
TCI teeth have moderate extensions.

Gage area has all dome type cutters to maximize cutter gage life.

### TYPE 5 (IADC)

Medium rock  
41–103 Mpa (6,000 - 15,000 PSI) compressive strength rock

**Formation types:** Limestone, sandstone, and shale.

TCI teeth are aggressive conical shaped for aggressive penetration rates in medium type rock.

### TYPE 8 (IADC)

Hard rock  
172–310 Mpa (25,000 - 45,000 PSI) compressive strength rock

**Formation Types:** Quartz, basalt, and quartzite.

TCI teeth are all hemispherical shape, providing a longer cutter life in extremely hard rock.

Lo-Torque Hole Opener Cutters to match the formation hardness of your bore.

The Lo-Torque Tungsten Carbide Cutter types now range from medium to extremely hard rock formations. Close attention to insert material composition of gage, inner row and base areas of the cutters optimizes their performance in the wide range of rock conditions encountered in horizontal drilling.

## Body and cutter weights – in kg

Body	LT2 – 15		LT4 – 51		LT6 – 121		LT8 – 218		LT16 – 539		LT24 – 885		LT32 – 1230		LT40 – 1451		LT48 – 1545														
Body	LT2	LT4	LT6		LT8		LT16		LT24		LT32		LT40		LT48																
	2"	8"	10"	12"	12"	14"	16"	16"	18"	20"	22"	24"	26"	28"	30"	32"	34"	36"	38"	40"	42"	44"	46"	48"	50"	52"	54"	56"	58"	60"	62"
MT	1.3	1.8	3.6	5.4	6.8	10.4	14.0	14.5	21.3	29.0	38.2	14.5	21.3	29.0	38.2	14.5	21.3	29.0	38.2	14.5	21.3	29.0	38.2	14.5	21.3	29.0	38.2	14.5	21.3	29.0	38.2
TCI	1.3	2.7	4.5	7.3	9.5	13.6	19.0	18.6	27.6	35.7	45.3	18.6	27.6	35.7	45.3	18.6	27.6	35.7	45.3	18.6	27.6	35.7	45.3	18.6	27.6	35.7	45.3	18.6	27.6	35.7	45.3

\* Weight in kg per cutter

Prime Horizontal offices

www.primehorizontal.com

## United States, Canada, Mexico, Brazil

Prime Horizontal Inc  
7710 Harms Road, Houston, TX 77041 US  
Ph (US): +1 346 998 1180  
Ph (CA): +1 780 800 6614  
Ph (BRZ): +55 71 3023 0934

## Europe, China, Middle East

Prime Horizontal Ltd  
Salland 3  
1948 RE Beverwijk  
The Netherlands  
Phone: +31 251 271 790


## Australia, Southeast Asia, India

Prime Horizontal Australia Pty Ltd  
10 Enterprise Street, Cleveland,  
QLD 4163, Australia  
Ph (AUS): +61 73 821 3684  
Ph (IND): Phone: +91 997 172 9753



# Lo Torque Hole Opener

Operating specifications– Metric sizes



Body type	Pilot hole	Body thread P x B	No. of cutters	cutter series	Opening size (cm)	Mill Tooth		TCI		Body OD (cm)	OAL*
						WOB (000's kg)	RPM's	WOB (000's kg)	RPM's		
LT2	6.4	2" IF	3		15.2	1.4 – 3.2	50 – 80	1.4 – 3.2	30 – 60	6.35	60.96
LT4	11.4	2 7/8" IF	3		20.3 – 30.5	3.6 – 4.5	50 – 90	4.5 – 5.4	40 – 80	8.89	95.25
LT6	16.5	3 1/2" IF	3		30.5 – 40.6	4.5 – 6.8	40 – 100	6.8 – 9.1	35 – 90	11.43	111.76
LT8	21.6	4 1/2" IF	3	A	40.5	6.8 – 9.1	40 – 100	9.1 – 18.1	35 – 90	16.51	123.19
				B	45.7	6.8 – 9.1	40 – 90	9.1 – 18.1	35 – 80		
				C	50.8	6.8 – 9.1	40 – 80	9.1 – 18.1	35 – 80		
				D	55.9	6.8 – 9.1	40 – 75	9.1 – 18.1	35 – 70		
LT16	40.6	7 5/8" Reg.	3	A	61.0	6.8 – 11.3	40 – 75	9.1 – 18.1	35 – 70	24.13	135.89
				B	66.0	6.8 – 11.3	40 – 75	9.1 – 18.1	35 – 70		
				C	71.2	6.8 – 11.3	40 – 75	9.1 – 18.1	35 – 70		
				D	76.2	6.8 – 11.3	40 – 65	9.1 – 18.1	35 – 60		
LT24	61.0	7 5/8" Reg.	4	A	81.3	6.8 – 13.6	35 – 60	9.1 – 22.7	35 – 55	24.13	148.59
				B	86.4	6.8 – 13.6	35 – 60	9.1 – 22.7	35 – 55		
				C	91.4	6.8 – 13.6	35 – 60	9.1 – 22.7	35 – 55		
				D	96.5	6.8 – 13.6	35 – 60	9.1 – 22.7	35 – 55		
LT32	81.3	7 5/8" Reg.	4	A	101.6	6.8 – 13.6	35 – 55	9.1 – 22.7	35 – 50	24.13	148.59
				B	106.7	6.8 – 13.6	35 – 55	9.1 – 22.7	35 – 50		
				C	111.8	6.8 – 13.6	35 – 55	9.1 – 22.7	35 – 50		
				D	116.8	6.8 – 13.6	35 – 55	9.1 – 22.7	35 – 50		
LT40	101.6	7 5/8" Reg.	4	A	121.9	6.8 – 13.6	35 – 50	9.1 – 22.7	30 – 45	24.13	148.59
				B	127.0	6.8 – 13.6	35 – 50	9.1 – 22.7	30 – 45		
				C	132.1	6.8 – 13.6	35 – 50	9.1 – 22.7	30 – 45		
				D	137.2	6.8 – 13.6	35 – 50	9.1 – 22.7	30 – 45		
LT48	121.9	7 5/8" Reg.	5	A	142.2	6.8 – 15.9	35 – 45	9.1 – 27.2	25 – 40	24.13	148.59
				B	147.3	6.8 – 15.9	35 – 45	9.1 – 27.2	25 – 40		
				C	152.4	6.8 – 15.9	35 – 45	9.1 – 27.2	25 – 40		
				D	157.5	6.8 – 15.9	35 – 45	9.1 – 27.2	25 – 40		

**Tips:**

- Softer formations will normally respond to lighter weights and higher RPM's. Harder formations require more weight and slower RPM's
- Adjust weight and RPM to achieve optimum torque. Avoid uneven rotation of hole opener.
- Use sufficient fluid volume to obtain optimum hole cleaning.
- Proper centralisation will enhance tool performance and increase downhole life.

\* Lengths apply for new bodies only.

The suggested weights and RPM's are only a recommended guide. Weights and RPM's should be adjusted to maximum penetration rates. They will vary with formation and rig power. Recommended weights assume minimum pilot hole sizes. As the cutting shoulder is reduced, less weight is needed.

Prime Horizontal offices

[www.primehorizontal.com](http://www.primehorizontal.com)

## United States, Canada, Mexico, Brazil

Prime Horizontal Inc  
7710 Harms Road, Houston, TX 77041 US  
Ph (US): +1 346 998 1180  
Ph (CA): +1 780 800 6614  
Ph (BRZ): +55 71 3023 0934

## Europe, China, Middle East

Prime Horizontal Ltd  
Salland 3  
1948 RE Beverwijk  
The Netherlands  
Phone: +31 251 271 790

## Australia, Southeast Asia, India

Prime Horizontal Australia Pty Ltd  
10 Enterprise Street, Cleveland,  
QLD 4163, Australia  
Ph (AUS): +61 73 821 3684  
Ph (IND): Phone: +91 997 172 9753